## Handout Review Creating Users\_Group and Setting Ownership and Permissions

- 1. Add a new user using the Shell
  - i. Enter sudo useradd -m newstudent
  - ii. Enter password for the password
  - iii. Type cat /etc/passwd to verify that newstudent user account was added to the system
  - iv. Can also type grep newstudent /etc/passwd to verify user account
  - v. Note the UID and GID numbers
  - vi. Change the password from password to newstudent using the following command
  - vii. Enter sudo passwd newstudent
  - viii. Enter newstudent twice to confirm password update
  - ix. Should receive response indicating that the password has updated successfully
- 2. Create a new group
  - i. Add group 1500 to the system and assign GID linuxstudents
  - ii. sudo groupadd -g 1500 linuxstudents
  - iii. Enter cat /etc/group to verify
  - iv. Enter id newstudent to view current list of groups for newstudent
- 3. Change ownership
  - i. Create a file called testfile
  - ii. Enter touch testfile
  - iii. Enter Is -I
  - iv. Current owner is YOU, change owner to newstudent
  - v. sudo chown newstudent testfile
  - vi. Is -I to verify new file owner
  - vii. Use previous command in step v to change back to YOUR user account
- 4. Permissions
  - i. Enter Is -I
  - ii. Default permissions for testfile is shown as -rw-rw-r—
  - iii. Or the octal translation is 664
  - iv. Change permissions to 755 on testfile
  - v. Enter sudo chmod 755
  - vi. Enter Is -I
  - vii. Permissions should no reflect the following code symbolically -rwxr-xr-x